



\*↔ solder both sides of board

notch

NB.  
C16 soldered to top surface only, bend legs 90 to form 'feet'

D1 is soldered on the underside of the board

snip the 'feet' off SK3 so it lays directly on the pcb.



Alternative BS250P (from top)

4mm HOLE for battery leads

board 2.5"x3.5"

ROX-1

G3Z01 v 2.02 18/12/03